


# opk E-Space Push and Open Mounting Instruction

## Single system / Schiene



## Double systems / Schienen (synchro system)

Refer to single system to install double systems

